## Aeroprakt A32 Vixxen

# Pre-flight inspection checklist

#### Entire airplane

- 1. Covers and control locks
- 2. Airplane rainwater, snow, frost, ice and dirt
- Rigging
- 4. External damage

#### Power plant

- 1. Propeller & spinner
- 2. Top cowling
- 3. Oil, coolant, and hydraulic fluid
- 4. Engine mount & vibration dampers
- 5. Cables and hoses
- 6. Fuel, oil, coolant leaks
- 7. Exhaust system joints and springs
- 8. Top cowling
- 9. Cowling and camlocs

#### Landing gear

- 1. Wheel spats (if fitted)
- 2. Tyre pressures
- 3. Tyres
- 4. Main wheel brakes
- 5. Hydraulic fluid
- 6. Nose and main legs
- 7. Nose leg shock absorber

## **Right wing**

- 1. Wing and strut
- 2. Wing and strut attachment fittings and bolts
- 3. Wing fuel tank cap remove & dip fuel, replace
- 4. Fuel cap vent outlet
- 5. Fuel leaks
- 6. Wing tip and navigation/strobe light
- 7. Control locks
- 8. Flaperon
- 9. Flaperon hinge brackets
- 10. Flaperon control linkage attachment

## Foxbat Australia

Foxbat Australia Pty Ltd, PO Box 237, Black Rock, Victoria 3193, Australia www.foxbat.com.au 03 9592 3101 (landline) 0413 900 892 (mobile/cell)

- REMOVED
- CLEAN
- CHECK visually
- NONE
- OK & SECURE
- REMOVE for inspection
- CHECK levels
- NO CRACKS and OK
- OK & SECURE
- NONE
- NO BROKEN SPRINGS
- RE-INSTALL
- OK & LOCKED
- CLEAN, SECURE, OK
- OK
- NO DAMAGE, WEAR OK
- CLEAN, SECURE, OK
- NO LEAKS
- NO CRACKS & OK
- OK & SECURE
- CLEAN & OK
- IN PLACE, SECURE, OK
- IN PLACE & SECURE
- CLEAN & OK
- NONE
- OK & SECURE
- REMOVED
- CLEAN & OK
- HINGES GREASED
- OK & SECURE

## Aeroprakt A32 Vixxen

# Pre-flight inspection checklist

– CLEAN & OK

- CHECK visually

- CLEAN, OK

- REMOVED

- OK & SECURE

- OK & SECURE

- OK & SECURE

- OK & SECURE

- CLEAN & OK

- OK & SECURE

- OK & SECURE

- CHECK visually

- CHECK visually

- OK & SECURE

- CLEAN & OK

- CLEAN & OK

- OK & SECURE

- OK & SECURE

- REMOVED

- NONE

- HINGES GREASED

- IN PLACE & SECURE.

- IN PLACE, SECURE, OK

– COVER OFF, CLEAN & OK

– OK

- CLEAN, NO CRACKS

- CLOSED, NO FUEL LEAKS

- OK. SECURE & GREASED

- CLEAN, & NO CRACKS

- DRAIN & CLOSE VALVE

## Right side of fuselage

- 1. Fuselage surface
- 2. Cockpit glass
- 3. Door hinges and locks
- 4. Recovery system condition (if fitted)
- 5. Drain valve under fuselage
- 6. Fuel test

#### Stabiliser & elevator

- 1. Surfaces
- 2. Clamps/stops
- 3. Horizontal stabiliser fittings and bolts
- 4. Stabiliser anti-servo tab
- 4. Rudder and trim tab
- 5. Rudder hinges
- 6. Tail surface attachment

## Left side of fuselage

- 1. Fuselage surface
- 2. Cockpit glass
- 3. Door hinges and lock
- 4. Battery and power cables attachment
- 5. Control system linkages
- 6. Baggage container condition

## Left wing

- 1. Flaperon control linkage attachment
- 2. Flaperon hinge brackets

10. Wing and strut surface

11. Pitot/static pressure probe

- Flaperon
- 4. Control locks

January 2016

- 5. Fuel leaks
- 6. Wing fuel tank cap remove & dip fuel, replace

9. Wing and strut attachment fittings and bolts

Fuel cap vent outlet
Wing tip and navigation/strobe light

## Aeroprakt A32 Vixxen

## Pre-start & take-off checklist

#### Cockpit

- 1. Cabin
- 2. Seats
- 3. Harness
- 4. Doors
- 5. Flight planning
- 6. Maps, docs required
- 7. Baggage
- 8. Starter kev
- 9. All electric switches
- 10. Flight instruments
- 11. Controls
- 12. Controls, rudder, elevator trim
- 13. Flaps
- 14. Park brake
- 15. Parachute safety pin (if fitted)

## **Engine starting**

- 1. Starter kev
- 2. Fuel levels
- 3. Fuel valves
- 4. Throttle
- 5. Doors
- 6. Carburetor heat (cold engine only)
- Choke lever (cold engine only) 7.
- 8. Propeller
- 9. Starter key (cold engine only - IGN OFF) - START FOR 5 SECS

Foxbat Australia Pty Ltd, PO Box 237, Black Rock, Victoria 3193, Australia www.foxbat.com.au 03 9592 3101 (landline) 0413 900 892 (mobile/cell)

- Ignition switches 10.
- 11. Starter key
- 12. Throttle
- 13. Choke lever
- 14. Carburetor heat (if fitted)
- 15. Engine
- 16. Required electrical equipment/insts

Foxbat Australia

## - CLEAN, NO LOOSE OBJECTS

- OK. ADJUSTED & SECURE
- OK, ADJUSTED & SECURE
- CLOSED & SECURE
- PERFORMED
- AVAILABLE & STOWED
- SECURED, ZIPPER CLOSED
- REMOVED
- OFF
- OK, CHECK, ADJUST READINGS
- FREE & FULL
- NEUTRAL/SET TRIM
- CHECK & RETRACT
- ON
- REMOVE
- INSERT, TURN TO ON
- CHECK BOTH
- CHECK BOTH ON
- SET TO IDLE
- CHECK CLOSED
- ON
- FULLY FORWARD
- CHECK 'CLEAR PROP!'

  - ON
- START (10 SECS MAX)
- SET 1.800-2.200 RPM – FULLY BACK SLOWLY
- REMAIN ON
- WARM UP 2,000-2,400 RPM
- ON & ADJUST

## Aeroprakt A32 Vixxen

## Pre-start & take-off checklist

## Taxiing

- Throttle 1.
- 2. Parking brake
- 3. Temperature & pressures
- 4. Taxi-way
- 5. Carburetor heat (if fitted)
- 6. Throttle
- Elevator 7.
- 8. Ailerons
- 9. Brakes
- Emergency stop 10.

## Engine check

- Face into wind 1.
- 2. Brakes & park brake
- 3. Throttle
- Check both ignition circuits 4.
- Oil pressure at 4,000 5.
- 6. Temperatures
- 7. Engine idle

## Before take-off

- At runway entry 1.
- 2. Brakes
- Cylinder Head Temperature 3.
- Oil temperature 4.
- 5. Fuel level

January 2016

- Fuel valves 6.
- Flaps (wind under 16 kts) 7.
- Flaps (wind over 16 kts) 8.

## Speeds at MTOW 600 kgs

Stall speed with full flap	27kts
Stall speed clean	33kts
Maximum flap speed	81 kts
Vanoeuvering	81kts
Never exceed	125kts
Best angle of climb	56kts
Best rate of climb	65kts

- IDLE
  - OFF

- OFF

- ON

- STOP

- ENGAGE

- FLAPS UP

Engine speeds (rpm, engine warm)

Best glide (no flap)

Best glide (with flap)

Minimum idle (check)

Maximum continuous

Maximum (5 mins max)

Normal idle

– 4,000 rpm

- WITHIN LIMITS

- CHECK - CHECK CLEAR

- NEUTRAL

- SET REQUIRED TAXI SPEED

- AS NEEDED, THROTTLE IDLE

- 300 rpm MAX DROP PER SIDE

- MIN 1400rpm, set 1800-2000rpm

- 115 rpm MAX DIFFERENCE

- CHECK 29-73 PSI (2-5 BAR)

- CHECK MIN 60°C (140°F)

- CHECK MIN 50°C (120°F)

- EXTEND TO POSITION 1

55kts

49 kts

1,400

5,500

5,800

1,800-2,000

- CHECK SUFFICIENT

- CHECK BOTH ON

- AGAINST CROSSWIND

- IGNITION OFF & BRAKE

- CHECK CLEAR BEHIND